

EVION PWR Pack

NL Handleiding

EN Manual

Model: EVION PWR Pack

Contact:

BE Leisure BV

Bremere 43

4724 HD Wouw

Netherlands

+31 6 800 70 268

Nederlands

Inleiding

Van harte gefeliciteerd met uw aankoop van een EVION PWR Bank.

De EVION PWR Pack voor het opladen van verschillende apparaten aan de waterkant. Ontworpen om zelfs de meest vragende apparaten op te kunnen laden of van stroom te voorzien. Mogelijkheid om meerdere apparaten tegelijk aan te sluiten op de Power bank.

Lees deze handleiding zorgvuldig voordat het product in gebruik genomen wordt. Het niet zorgvuldig naleven van deze aanwijzingen kan leiden tot ernstig lichamelijk letsel of schade aan eigendommen. Bij onjuist gebruik wordt garantie uitgesloten.

Inhoud pakket

Power Bank

Accessoires

Handleiding

1. LED meter
2. Aan/uit knop
3. 12V 15A aansluiting
4. 5V 2.4A / 5V 1.0A / 5V/2.1A USB poorten
5. 15V oplaadaansluiting
6. LED licht / waarschuwings licht

Installatie

- Haal alle onderdelen uit de verpakking en controleer of deze aanwezig zijn.
- Controleer of de goederen niet beschadigd zijn.
- Eventuele beschadigingen dienen binnen 7 dagen gemeld te worden.
- De accu en acculader dienen bewaard te worden in een overdekte omgeving.
- De omgevingstemperatuur is van invloed op de daadwerkelijke capaciteit van de accu. Bij koud weer zal de accu minder capaciteit leveren.

Gebruik van de PWR Bank om 12V apparaten te laden/gebruiken

- Apparaten zoals koelbox, opblaaspomp, drone accu's en oplaadbare lampen. (Maximaal 150W)
- Steek de stekker in de sigarettenaansteker, zorg voor een goede bevestiging
- De sigarettenaansteker zal automatisch het aangesloten apparaat van stroom voorzien
- Om het apparaat uit te schakelen: haal de stekker eruit.

Gebruik van de PWR Bank om 5V apparaten te laden/gebruiken

- Voor apparaten zoals: telefoons, tablets, camera's en andere 5V apparatuur.
- Steek de USB-kabel in een van de USB-poorten van de PWR Bank
- Sluit het apparaat aan op de USB-kabel
- Zet de PWR Bank aan met de aan/uit knop
- Uw apparaat wordt nu opgeladen/is te gebruiken

Gebruik van ingebouwde lamp

- Bij 2 keer snel achter elkaar op de aan/uit knop drukken zal het rode waarschuwingslicht aangaan. Nadien 2 keer snel drukken zal de lamp weer uitgaan.
- Wanneer enkele seconden de aan/uit knop ingedrukt wordt zal het witte licht aangaan. Om de lamp uit te schakelen dient u de knop weer enkele seconden ingedrukt te houden.

Belangrijke mededeling

De Power Bank is uitgerust met een automatische schakelaar. Indien de aangesloten apparaten meer dan 150W vragen zal de Power Bank uitgeschakeld worden. Voor een reset: haal alle kabels uit de Power Bank en sluit de Power Bank aan op 100v-24V AC-netvoeding.

Gebruik

- Voor een lange levensduur van de Power Bank: ontkoppel van netvoeding zodra de accu volledig is opgeladen
- Vermijd extreme kou, hitte of ontvlambare producten. Vermijd tevens vallen op een harde ondergrond.
- Het product is spatwaterdicht.
- Laad en ontlad de accu volledig eens per 4 maanden om te voorkomen dat de levensduur verkort wordt
- Wanneer het product langer niet gebruikt gaat worden raden wij aan om deze op 50% op te laden en te bewaren
- Gebruik altijd de originele lader die bij het product geleverd is
- Gebruik van de Power Pack beneden 0 °C en boven 40 °C wordt niet aangeraden aangezien dit de levensduur van de accu kan verkorten zo niet onherstelbaar kan beschadigen.

Laden

- Gebruik alleen de meegeleverde acculader.
- De accu's kunnen altijd geladen worden ongeacht de resterende capaciteit. (Altijd boven de 0 °C)
- Laden van de accu's kan tussen 0 °C en 45 °C graden. Beneden 0 graden is niet mogelijk.

Ontladen

- Volledig ontladen van de accu is niet schadelijk.
- Wanneer de accu volledig ontladen is dient deze zo snel mogelijk weer geladen te worden.

FAQ

- *Welke poort moet ik gebruiken om mijn apparaat aan te sluiten*
Alle USB-poorten kunnen gebruikt worden tot maximaal 2.4 Amps.
- *Kan ik de Power Bank gebruiken om 4 apparaten tegelijk te gebruiken/laden.*
Ja. De 12V 15A uitgang is onafhankelijk van de USB-poorten. Alle vier de poorten kunnen tegelijk gebruikt worden.
- *Wat te doen als de Power Bank niet wil opladen?*
Controleer of de oplader goed is aangesloten op de 100V – 240V netvoeding.
- *Mijn apparaat werkt niet op de Power Bank.*
Controleer of het aangesloten apparaat compatibel is met de Power Bank.

Garantie

- Standaard garantie op de Power bank is 1 jaar.
- Gevolgschade is uitdrukkelijk uitgesloten, zoals winstderving en of geleden verlies, bedrijfsschade, personen-of letselschade.

Technische gegevens

Model	EVION PWR Bank
Capaciteit	114Wh / 12A @ 12V
Laad voltage	15V 2A max
Gewicht	975g
Afmetingen (LxWxH)	175*105*42mm
CE keuring	Ja
Garantie	1 jaar



English

Introduction

Congratulations with your purchase of your EVION PWR Bank.

The Evion Power Pack for portable power on the bank or in the field. Designed to fulfill the needs of even the most powerfull consuming devices. It is designed to allow simultaneous use of the 12V socket and USB outputs.

Ideal for longer trips so you can charge your phone and tablet multiple times but also you can charge higher demanding devices. It boosts a high capacity of 144Wh / 12ah @ 12V or 38.000mAh @ 3,7V.

The rugged shell which includes a power indicator and light comes complete with port covers and carry case to ensure it is kept safe.

Read this instruction manual carefully before you start using your new product and maintaining your product. Follow the safety instructions, not doing so could cause injury or damage to your belongings. Not following the instructions of wrong usage may invalidate our warranty.

Contents of your package

Power Bank

Accessories

Instruction manual

Identification of parts:

1. LED power meter
2. Power button
3. 12V 15A socket
4. 5V 2.4A / 5V 1A / 5V 2.1A USB ports
5. 15V input socket
6. LED Light / Emergency warning light

Installation and usage

- Unpack your box and see if all parts are included.
- Inspect the products if they are not damaged.
- Damages need to be reported within 7 days.
- The battery and charger need to be stored in a dry environment.
- The temperature has influence on the performance on the battery. With cold weather, you will have less power available.

Using the Power Pack to charge/power a 12V device

- Support devices: car refrigerator, inflator pump, UAV Battery, outdoor camping light, fishing light etc (powered below 150W)
- Plug your device into the 12V cigar adapter socket of the Power Pack, ensuring a secure fit
- The socket will automatically power the connected device
- To turn off the device, unplug it from the Power Pack

Using the Power Pack to charge/power a 5V device

- Support devices: mobile phones, tablet, digital camera and other 5V devices.
- Plug an USB cable into one of the USB ports
- Attach your device to the cable
- Press the power button on the Power Pack
- Your device is now charging

Using the build-in light

- Push the power button rapidly two times to activate the red warning light. Push the button again two times switch off the red light
- Hold the power button for a couple of seconds to activate the white light. Hold the power button again the switch off the white light.

Important notice:

The Power Pack is fitted with an automatic switch. If a device attempts to draw more than 150W at any time, the internal protection circuit will activate and shuts down the Power Pack. To reset: unplug all connected devices and connect the Power Pack to a 100V-240V AC supply. (as per charging instruction)

Usage notes:

- To protect the long-term capacity of your Power Pack, please unplug the power wire promptly after the device is fully charged.
- Keep the product away from extreme heat or cold, as well as any flammable items or damp places. Also avoid impact on hard surfaces.
- This device is waterproof but can't be put into the water.
- Run a full charge/discharge cycle at least once every four months to avoid shortening the life span of the internal battery.
- If long term storage is likely to occur between uses, we recommend the store at approximately 50% of full charge.
- When supply power for different devices: a further 10% - 20% is lost by the device being discharged by multiple items.
- Always use the original cable for charging the Power Pack.
- Using your Power Pack in temperatures below 0 °C or above 40 °C is highly inadvisable and will likely cause irreparable damage to the internal battery.

Charging the battery

- Only use the supplied charger for the EVION PWR bank.
- Batteries can always be charged whatever the remaining capacity is. (but always above 0 °C)
- Charging can be done between 0 °C and 45 °C .

Discharge

- Fully discharging the battery is not harmful
- When the battery has been fully discharged, it needs to be charged as soon as possible again.

FAQ

- *Which port should I use to charge my device?*
The USB ports can charge at speeds of up to 2.4 amps, no need to decide between them.
- *Can I use the Power Pack to charge 4 devices at the same time?*
Yes. The 12V 15A output is independent of the 5V USB ports and all 4 can be used simultaneously.
- *What if the Power Pack fails to charge?*
Check if the adaptor connection is secure and the 100V-240V AC power source is turned on.
- *What if the Power Pack is not working on your device.*
Please make sure the used device is compatible with the Power Pack output.

Warranty

- Standard warranty on the batteries is 1 year.
- Consequential damage is explicitly excluded, such as loss of profit and / or loss, business loss or personal injury.

Technical specifications

Model	EVION PWR Bank
Rated Capacity	114Wh / 12A @ 12V
Charge Voltage	15V 2A max
Weight (approx.)	975g
Battery Dimension (L×W×H)	175*105*42mm
CE approved	Yes
Warranty	1 year

